



Guided Rebate Set 46/39



Please read carefully before use

BEARING GUIDED REBATE SET REF. 46/39

Thank you for purchasing this Trend router cutter, which should give lasting performance if used in accordance with these instructions.

The set enables fast and easy rebating by the use of the bearing. The depth of the rebate depends on the diameter of the bearing fitted.

The following symbols are used throughout these instructions.



Denotes risk of personal injury, loss of life or damage to the tool in case of non-observance of the instructions.



Refer to the instruction manual of your power tool.

This cutter must not be put into service until it has been established that the power tool to be connected to this unit is in compliance with 98/37/EC (identified by the CE marking on the power tool).

INTENDED USE

This cutter is intended to be used in a routing machine to create a rebate in wood and wood based material.

SAFETY

Please read and understand the safety points at the end of this instruction as well as the power tool instructions before use.

PLEASE KEEP THESE INSTRUCTIONS IN A SAFE PLACE.

The attention of UK users is drawn to The Provision and Use of Work Equipment Regulations 1998, and any subsequent amendments.

Users should also read the HSE/HSC Safe Use of Woodworking Machinery Approved Code of Practice and Guidance Document and any amendments.

Users must be competent in using woodworking equipment before using our products.

Attention should be made to the HSE's Safe Use of Vertical Spindle Moulding machines Information Sheet No. 18 and any revisions.


ITEMS REQUIRED

- Router with suitable collet fitted.
- Handtools.

ITEMS ENCLOSED & DESCRIPTION OF PARTS

- | | |
|---------------------------------|--------------------------------|
| A. Cutting tool x1 | G. Bearing 5/8" dia. x1 |
| B. 3/8" shield/washer x1 | H. Bearing 3/4" dia. x1 |
| C. 1/2" shield silver x1 | I. Washer x1 |
| D. 5/8" shield black x1 | J. Screw x1 |
| E. Bearing 3/8" dia. x1 | K. Kex key x1 |
| F. Bearing 1/2" dia. x1 | L. Instructions x1 |

Bearing Guided Rebate Set as supplied



Before use of cutter please ensure it is correctly assembled and locking screw is fully tightened.

The set is supplied with a B127A ball bearing fitted. When changing the bearing follow the sequence of the diagrams shown overleaf. Ensure that the correct shield is fitted and that the raised portion of the shield always faces the bearing.

The following rebate depths can be achieved.

The cutting height depends on the adjustment on the routing machine.

Bearing Ref. fitted	Diameter of bearing	Rebate depth
B95A	9.5mm (3/8")	12.7mm (1/2")
B127A	12.7mm (1/2")	11.1mm (7/16")
B16A	15.9mm (5/8")	9.5mm (3/8")
B19A	19.1mm (3/4")	7.9mm (5/16")

OPERATION



Carefully remove the protective wax from the cutter and dispose.

Insert the cutter shank into the collet at least all the way to the marked line indicated on the shank. This ensures at least 3/4 of the shank length is held in the collet.

Set the cutter height and rout the groove in the edge of the door or frame. A wider strip can be accommodated by changing the cutter height.



Recommended speed is 18,000rpm. PTO

ENVIRONMENTAL PROTECTION

Recycle raw materials instead of disposing as waste.

Packaging should be sorted for environmental-friendly recycling. The product and its accessories at the end of its life should be sorted for environmental-friendly recycling.


GUARANTEE

All Trend products are guaranteed against any defects in either workmanship or material, except products that have been damaged due to improper use or maintenance.

© Trend Machinery & Cutting Tools Ltd. 2009 E&OE
© All trademarks acknowledged

Trend Machinery & Cutting Tools Ltd.

Odhams Trading Estate St. Albans Road
Watford WD24 7TR England
Tel: 0044(0)1923 249911
technical@trendm.co.uk
www.trend-uk.com




5 027654 318911 >




RECYCLABLE


Rebate 12.7mm (1/2")




Rebate 11.1mm (7/16")



Rebate 9.5mm (3/8")



Rebate 7.9mm (5/16")



SPARE PARTS

Please use only Trend original spare parts.

Item	Qty.	Desc.	Ref. (1 off)
E	1	Bearing 9.5mm (3/8")	B95A
F	1	Bearing 12.7mm (1/2")	B127A
G	1	Bearing 16mm (5/8")	B16A
H	1	Bearing 19mm (3/4")	B19A
I	1	Hex Key 3/32 A/F	
J	1	Washer	SP-C
K	1	Screw	
L	1	Instructions	INST/46/39

MAINTENANCE

Continual satisfactory operation depends upon proper tool care and regular cleaning.

Cleaning

- Ensure clamping surfaces are cleaned to remove dirt, grease, oil and water.
- Remove resin build-up regularly. Apply a rust protector to shanks. Do not use rust protector on ball bearings guides.

Lubrication

- Use a PTFE dry lubricant spray on tool to increase cutting edge life.

Storage

- Always return cutter to its packaging after use.

Safety Points


- Disconnect power tool and attachment from power supply when not in use, before servicing, when making adjustments and when changing accessories such as cutters. Ensure switch is in "off" position and cutter has stopped rotating.
- Read and understand instructions supplied with power tool, attachment and cutter.
- Current Personal Protective Equipment (PPE) for eye, ear and respiratory protection must be worn. Keep hands, hair and clothes clear of the cutter.
- Before each use check cutter is sharp and free from damage. Do not use if cutter is dull, broken or cracked or if any damage is noticeable or suspected.
- The maximum speed (nmax) marked on tool or in instructions or on packaging shall not be exceeded. Where stated, the speed range should be adhered to.
- Insert the shank into the router collet at least all the way to the marked line indicated on the shank. This ensures at least 3/4 of shank length is held in collet. Ensure clamping surfaces are clean.
- Check all fixing and fastening nuts, bolts and screws on power tool, attachment and cutting tools are correctly assembled, tight and to correct torque setting before use.
- Ensure all visors, guards and dust extraction is fitted.
- The direction of routing must always be opposite to the cutter's direction of rotation.
- Do not switch power tool on with the cutter touching the workpiece.
- Trial cuts should be made in waste material before starting any project.
- Repair of tools is only allowed according to tool manufacturers instructions.
- Do not take deep cuts in one pass, take shallow passes to reduce the side load applied to the cutter.

Please see www.trend-uk.com/safety for more safety advice.




Our policy of continuous improvements mean that specifications may change without notice. Trend Machinery & Cutting Tools Ltd. cannot be held liable for any material rendered unusable, or for any form of consequential loss.


Wood profile with B95A



Wood profile with B16A



Wood profile with B127A



Wood profile with B19A

